



cover removes completely by pushing down buttons on both sides


mounting with screws




mounting with double faced adhesive







display your message vertical ...or horizontal



adjust easily the angle of your display!

